





ROOF TRIM STRIPS

NB. Cut out trim strips at two planks wide and apply them vertically to the corners and edges of the roof.

You will need to cut them to the required length and then fold them along their centre line to form the 'L' shaped corner mouldings.

Apply glue and carefully fit in place.

Check the photographs of the finished clock to determine the exact placement of the pieces.

SPOOKY HOUSE

Copyright Notice

SHEET 3

Your licence is for personal use only. Reselling, sharing or commercial use of these plans or artwork is not allowed.