## HELLO AND WELCOME TO YOUR BACKPACK

## Tools/skills of the trade:

RAW EDGE PLAIN TAPE BINDER - BINDING ATTACHMENT.



THE SPEED OF BUILDING THIS BAG IS BUILT AROUND THIS TOOL. IF YOUR SEWING MACHINE HAS THREADED POINTS THEN YOU CAN ADD THIS TO YOUR MACHINE.

THE ONE I USE IS LOCATED AT:
WWW.CUTEXSEWINGSUPPLIES.COM UNDER THE
NAME ABOVE. THE COST IS AROUND \$14

IF YOUR MACHINE DOES NOT HAVE THREADED POINTS, YOU CAN GET A FOOT THAT DOES THE SAME IF YOU SEARCH FOR BIAS TAPE BINDING FOOT.

IT IS HELPFUL FOR ANY PROJECT WHERE YOU ADD BINDING TAPE.

QUILTING PINS/PINNING: THEY ARE LONG AND HAVE VISIBLE HEADS.



PINNING IS THE KEY TO GETTING YOUR SEAMS TO LINE UP FROM THE BEGAINING TO THE FND.

START BY PINNING THE POINTS THAT HAVE LINES THAT HAVE CORRESPONDING MARKS AND PULL THE PINS BEFORE THE NEEDLE HITS THEM BUT NOT SO SOON THAT THE SEAM LOSES ITS PLACEMENT TOO BADLY.

THIS BAG HAS VERY MINIMAL PINNING AS IT CAN BE A TIME CONSUMING, IT ONLY REALLY HAS 2 LARGE PINNED SEAMS.

THE INSTRUCTIONS IN DIGITAL FORMAT:

THEY HAVE LOTS OF PICTURES AND THEY ARE GOOD QUALITY.

THIS MEANS THEY CAN BE ZOOMED IN ON TO SEE DETAILS WHEN SOMETHING IS AMBIGUOUS.