		Quantity	
Part Name	Picture	required	Print settings
2020 battery holder		1	Orientation shown. 0.3mm layer height. Use a skirt.
2020 battery protector spacer		2	Orientation shown. 0.3mm layer height.
2020 M3 T-nut		6	Orientation shown. 0.3mm layer height.
Assembly aid bracket.		4 (optional)	Orientation shown. 0.3mm layer height.
Baseplate mount		3	Orientation shown. 0 .3mm layer height.
Baseplate mount slim		1	Orientation shown. 0.3mm layer height.
Belt Tensioner		1	Orientation shown. 0.3mm layer height.

Brush gripper	1	Orientation shown. Use some supports. Use a skirt. 0.2mm layer height.
Camera mount	1	Orientation shown. 0.2mm layer height (to help with small overhangs).
Charging port	1	Orientation shown. 0.2mm layer height. Use supports.
Idler pulley spacer	2	Orientation shown. At least 0.3mm layer height. Use a skirt.
Lid dowel drill guide	1	Orientation shown. 0.3mm layer height.
Limit switch cover	2	Orientation shown. At least 0.3mm layer height.
MGN9 1mm spacer	4	Orientation shown. 0.2mm layer height.

MGN9 cutting guide	1 (optional)	Orientation shown. At least 0.3mm layer height.
Paper clamp bottom	4	Orientation shown. 0.2mm layer height.
Paper clamp top	4	Orientation shown. 0.3mm layer height.
PCB angle spacer	2	Orientation shown. 0.3mm layer height.
Presser foot	1	Orientation shown. 0.3mm layer height.
Presser foot handle	1	Orientation shown. 0.3mm layer height.
Servo bracket	1	Orientation shown. Use some supports. 0.2mm layer height.

X-axis carriage	1	Orientation shown. Use some supports. 0.2mm layer height.
Y-carriage LHS	1	Orientation shown. 0.2mm layer height.
Y-carriage RHS	1	Orientation shown. 0.2mm layer height.
Y-carriage spacer	4	Orientation shown. 0.3mm layer height. Use a skirt.
Y-carriage top	2	Orientation shown. 0.3mm layer height. Use CURA 'iron' setting for a nice finish on the top.
Total:	48	I