

# Step 3. 90° Nylon Print

Using binder stretch the mesh across the whole bed. Make sure the clips don't interfere with the bed z axis. Make Sure the top is somewhat level some small bumps are okay. When the auto level comes down make sure it taps slightly above the mesh for a more consistent print

