

Step 4. Trim and Heat Press

Once off the print bed you can finally take the base and the new layer off after unclipping the binders. Trim the mesh so none is directly exposed. This next step can either be done with a heat press or super glue, but its purpose is to seal any imperfections in the print.

Heat Press

Place the whole trimmed print into the press in between teflon barriers. Heat to 250° and apply pressure for 30 seconds.

Super Glue

When weight is applied to the bottom look for weak points of adhesion between the top and base layer. Apply super glue.

