

Template 1

1. Cut on dotted lines and mount paper template to body blank.
2. Counterbore Wing Bolt holes to .56" depth with a 3/8" forstner or bradpoint bit and drill through with a 7/32" bit.
3. Drill Tone and Volume holes with a 5/32" bit to a depth of 1/4"
4. Drill switch hole with a 1/8" bit to a depth of 1/4".
5. Remove material in pickup and neck cutouts to prepare for routing. The tip of the forstner bit should be 1/16 to 1/8 above the final routed depth. The pickups are routed to a depth of 3/4" and the neck is routed to 5/8".

