

Template 3

Wing Offset Template

1. Cut on outer line and mount paper template to 1/2" MDF.

Routing

1. Check with your router specs but I used the template plus a 3/4" spacer below this template.
2. I used a 1/2" router bit for this cut.
3. Route to a depth of 1/16" or the thickness of your control cavity cover.

