

CASE CONSTRUCTION - STEP ONE

THE PERSPEX FITS IN THE GROVES OF THE CORNERS.
THE PCB FITS BEHIND THE CORNERS

MINUTE LIGHT SURROUND
GLUE WITH DROP OF SUPER-GLUE TO BACK PIN

BLACK BLANK
PLACED BETWEEN
THE PERSPEX AND
CORNER TO HIDE
SCREW HEAD

