

# Free connector template

Cardboard does not go on the tabs.

|                  |   |                             |   |          |
|------------------|---|-----------------------------|---|----------|
| Inner shell<br>3 | 1 | Attach to<br>end bit<br>one | 2 | Tab<br>3 |
|------------------|---|-----------------------------|---|----------|

|                  |  |                             |  |          |
|------------------|--|-----------------------------|--|----------|
| Inner shell<br>2 |  | Attach to<br>end bit<br>two |  | Tab<br>2 |
|------------------|--|-----------------------------|--|----------|

|                  |                |  |                |          |
|------------------|----------------|--|----------------|----------|
| Outer shell<br>1 | Attach<br>to 1 |  | Attach<br>to 2 | Tab<br>1 |
|------------------|----------------|--|----------------|----------|

End bit1

End bit2

B4

B4

|  |  |    |  |  |
|--|--|----|--|--|
|  |  | B4 |  |  |
|--|--|----|--|--|