

To AstroSplash
Power switch, Red
wire +V

To AstroSplash
12V socket Black
wire 0V

Arduino 16X2 LCD
with I2C serial
board

To Astrosplash BNC
TEST centre pin

To AstroSplash BNC
TEST outer

A4-----SDA
A5-----SCL

