



This pull-up resistor is soldered directly on the board

Power pins of Atmega32 is not shown. Connect pin #10 to 5v\_DC rail and pin #11 to GND rail