


LCD SUB MENU: Display RSSI

Purpose: Display station Received Signal Strength Indicator (RSSI) in dBm as reported by the LoRa Radio



Press **UP** & **DOWN** buttons to cycle through stations
Press **ENTER** button to return to the LCD Main Menu