


# SKETCH TOUCHSCREEN MUSICBOX WITH LIGHT SHOW



Upper panel: provided with excision for speaker

Left & right panel:  
left provided with excision USB+POWER  
provided with excision for potentiometer

Front panel: provided with excision for touchscreen

Base panel: for mounting of both side panels + front and back