


## LCD SUB MENU: Set Alerts

Purpose: Enable and disable alerts for stations



Press **UP & DOWN** buttons to cycle through the Station Menu showing alert status for each station  
Press **ENTER** button once to edit alert status for the selected station  
Press **FUNC** button to return to the LCD Main Menu from the Station Menu

Press **UP & DOWN** buttons to cycle alert status ON and OFF  
Press **ENTER** button a second time to return to the Station Menu