


LCD SUB MENU: Set Number of Stations

Purpose: Set the number of active stations in the system



Press **UP** & **DOWN** buttons to increment & decrement the number of active stations, respectively
Press **ENTER** button to return to the LCD Main Menu