


## LCD SUB MENU: Set Temperature Units

Purpose: Select either Fahrenheit or Centigrade units for temperature display



Press **UP** & **DOWN** buttons to toggle between Fahrenheit and Centigrade units

Press **ENTER** button to save selection and return to the LCD Main Menu