


LCD SUB MENU: Set Time Zone

Purpose: Set the local time zone. Twenty-four time zones supported, identified by major city and offset from UTC.



Press **UP** & **DOWN** buttons to increment & decrement the Time Zone by one hour, a major city and offset from UTC is displayed for each Time Zone.
Press **ENTER** button to select the Time Zone and return to the LCD Main Menu