Adjustable Thermostatic Relay

Model: AIOT-ATR-USB

Relay ▶

Power (USB 5V) ◀

Power ○

Relay ON ○

Push to Set

Heating

Trigger temp adjustment

Cooling

Current Temperature

Temp Probe ▶

Instructions for 3D Project Case:

First do a test print on regular paper at 100% size. If your program does not allow force print at 100% or the image seems to large, use the pdf version of the file which can also be found in the ressources folder and make sure to select "print actual size". Once statisfied with the print size and quality, print on you glossy sticker label paper and cut along crosshairs.