Paper Wallet Folding Instructions

White side = non-printed side
grey side = printed side

Print side on back.

white (back) side

①
Fold along line A and B
so the edges of the paper
meet at C (print side out)

②
Fold inward
along line C

③
Fold inward
along line D

④
Unfold everything, and
cut along the dashed lines,
including the hole in the
center

⑤
Fold tabs 2, 4, 6 & 8
to the non-printed side.

⑥
Repeat steps 1 and 2

⑦
Tuck tab 1 into the
opening between
tabs 3 and 4

⑧
Tuck tab 3 into the
opening between
tabs 1 and 2

⑨
Repeat the process on the
other side by tucking tab 5
between tabs 7 and 8, and
tab 7 between tabs 5 and 6